



- ❶ Retrieve the Remote Control from its storage location at the back of TV behind the table stand.
- ❷ Plug the A/C Power Supply into the wall outlet and insert the other end into the power jack located on the bottom right side of the TV.
- ❸ Using the switch just above the power jack or the red power switch on the remote control, turn on the TV and verify that the green power light is on.
- ❹ Connect and extend the whip antenna or connect an external antenna or connect a cable from your cable system.
- ❺ Press the Menu button on the remote control.
- ❻ Navigate to the Setup Menu (far right menu) using the Vol+ button.
- ❼ Press the CH- button to select Antenna.
- ❽ Use the Vol+ button to select AIR for the whip or external antenna or CATV for a cable TV connection.
- ❾ Press the CH- button to select the Auto Scan.
- ❿ Press the Vol+ button twice to initiate the Auto Scan or Vol+, CH- and Vol+ to initiate the Auto Scan for CATV.
- ⓫ The display screen will show the current channel being scanned and the number of channels found - this may take 2 to 3 minutes to complete.



- ❿ Setting up NTSC for A/V input.
 - Choose the A/V input by pressing the mode button at the top of the remote and scroll to "AV IN".
 - Once you have selected A/V in, press the "Menu" button.
 - On the menu, scroll right to the "Gear" icon.
 - Select the gear icon and scroll down to "Video System".
 - At "Video System, select "NTSC" as the type.
 - Press "Enter".
 - Press "Menu" to clear the menu from the screen.
- ⓫ Enjoy your new Access HD TV!

**Navigating within the Menu can also be performed using the side pannel TV control buttons. It may be necessary to re-scan for channels when travelling to different locations.*