
30SB Collector Housing Diagram 16 ယ 4 6 811= ග 12 14 2 640 640 640 640 640 640 640 5 20012 20012 // 닯 5 e Fiii () ETT () ETT () ETT () ETT () ETT () ETT () တ ∞ **∞** 17


30SB Collector Assembly Diagram Key - Up To Year Model 2019			
ltom#	GXi Part	Description	
Item#	Number	Description	
		Discharge chute assembly, SB orange, with labels, hand guard, hand guard spring,	
1	B00510	deflector, deflector seal, plastic rotation ring, chute mounts and spacers, deflector	
		cable, and hardware	
2	B00710	Discharge chute deflector, SB orange, slotted deflector guides, with deflector seal	
		and hardware	
3	B00910	Drift cutters, set of 2, SB orange, with hardware	
4	B01412	Auger/Impeller gear box, SB, SS	
5	B01512	Discharge chute rotation ring, SB, SS, black chute mount tabs, chute mount spacers with steel tube inserts, and hardware	
6	B02410	Snow cleanout tool with mounting bracket and hardware	
7	B03712	Discharge chute direction gear (spiral gear), SB, SS, with threaded chute cable connection, cotter pin, plastic bushing, flat washer, and hardware	
8	B04811	Auger/Impeller clutch pulley assembly, SB, SS, includes clutch arm, idle pulley, hardware, brake spring with spring mount, and pivot bushing	
9	B05111	Auger/Impeller pulley, SB, SS, double V, with key and mounting hardware - loctite recommended (not included)	
10	B06511	Impeller, SB, SS, welded 3 blade impeller with hardware	
11	B06811	Auger shaft bearings, SB, SS, collector housing end, with plastic bushing, bearing housing and hardware	
12	B06911	Gear box support bar, SB, SS, black reinforcement, with top reinforcement plate, and hardware.	
13	B07111	Skid shoes, set of 2, steel, reversible, SB orange, with hardware	
14	B10912	30" Scraper blade assembly, 30SB, 30SS, black, with hardware, scrapper blade	
14		assembles to bottom of collector housing with carriage bolt heads down.	
15	B08211	Impeller shaft main bearing with support bracket and hardware, SS, SB, black	
16	B09511	30" Snow collectors (augers), set, 30SB, 30SS, black only replacements	
17	B08914	Auger/Impeller belt set of 2, SB, SS, aramid fiber MXV4-370	
18	B08112	Collector assembly hardware kit, SB, SS	
19	B06711	Shear bolts, package of 10 with locking hardware	


36 SB Collector Housing Diagram -8 8 16 ယ 4 **1**0 811= 8 =0 8 =0 ග 12 14 2 വ // ည 5 iii 000 40 000 40 000 40 000 40 000 40 000 40 00 40 00 40 000 G \odot **~** 011 =0 011 =0 011 =0 011 =0 011 =0 17


36SB Collector Assembly Diagram Key - Up To Year Model 2019			
Item#	GXi Part Number	Description	
1	B00510	Discharge chute assembly, SB orange, with labels, hand guard, hand guard spring, deflector, deflector seal, plastic rotation ring, chute mounts and spacers, deflector cable, and hardware	
2	B00710	Discharge chute deflector, SB orange, slotted deflector guides, with deflector seal and hardware	
3	B00910	Drift cutters, set of 2, SB orange, with hardware	
4	B01412	Auger/Impeller gear box, SB, SS	
5	B01512	Discharge chute rotation ring, SB, SS, black chute mount tabs, chute mount spacers with steel tube inserts, and hardware	
6	B02410	Snow cleanout tool with mounting bracket and hardware	
7	B03712	Discharge chute direction gear (spiral gear), SB, SS, with threaded chute cable connection, cotter pin, plastic bushing, flat washer, and hardware	
8	B04811	Auger/Impeller clutch pulley assembly, SB, SS, includes clutch arm, idle pulley, hardware, brake spring with spring mount, and pivot bushing	
9	B05111	Auger/Impeller pulley, SB, SS, double V, with key and mounting hardware - loctite recommended (not included)	
10	B06511	Impeller, SB, SS, welded 3 blade impeller with hardware	
11	B06811	Auger shaft bearings, SB, SS, collector housing end, with plastic bushing, bearing housing and hardware	
12	B06911	Gear box support bar, SB, SS, black reinforcement, with top reinforcement plate, and hardware.	
13	B07111	Skid shoes, set of 2, steel, reversible, SB orange, with hardware	
14	B07211	36" Scraper blade assembly, 36SB, 36SS, black, with hardware	
15	B08211	Impeller shaft main bearing with support bracket and hardware, SS, SB, black	
16	B08311	36" Snow collectors (augers), set, 36SB, 36SS, black only replacements	
17	B08914	Auger/Impeller belt set of 2, SB, SS, aramid fiber MXV4-370	
18	B08112	Collector assembly hardware kit, SB, SS	
19	B06711	Shear bolts, package of 10 with locking hardware	



45SB Collector Assembly Diagram Key - Year Model 2012/13		
Item#	GXi Part Number	Description
1	B00512	Discharge chute assembly, SB orange, with labels, hand guard, hand guard spring, deflector, deflector seal, plastic rotation ring, chute mounts and spacers, deflector cable, and hardware
2	B00712	Discharge chute deflector, SB orange, with deflector seal and hardware
3	B00910	Drift cutters, set of 2, SB orange, with hardware
4	B01412	Auger/Impeller gear box, SB, SS
5	B01512	Discharge chute rotation ring, SB, SS, black chute mount tabs, chute mount spacers with steel tube inserts, and hardware
6	B02410	Snow cleanout tool with mounting bracket and hardware
7	B03712	Discharge chute direction gear (spiral gear), SB, SS, with threaded chute cable connection, cotter pin, plastic bushing, flat washer, and hardware
8	B04812	Auger/Impeller clutch pulley assembly, SB, SS, includes clutch arm, idle pulley, hardware, brake spring with spring mount, and pivot bushing
9	B05112	Auger/Impeller pulley, SB, SS, double V, with key and mounting hardware - loctite recommended (not included)
10	B06511	Impeller, SB, SS, welded 3 blade impeller with hardware
11	B06811	Auger shaft bearings, SB, SS, collector housing end, with plastic bushing, bearing housing and hardware
12	B06912	Gear box support bar, SB, SS, black reinforcement, with top reinforcement plate, and hardware.
13	B07111	Skid shoes, set of 2, steel, reversible, SB orange, with hardware
14	B11012	45" Scraper blade assembly, 45SB, 45SS, black, with hardware, scrapper blade assembles to bottom of collector housing with carriage bolt heads down.
15	B08211	Impeller shaft main bearing with support bracket and hardware, SB, SS, black
16	B08411	45" Snow collectors (augers), set, 45SB, 45SS, black only replacements
17	B08914	Auger/Impeller belt set of 2, SB, SS, aramid fiber MXV4-370
18	B08112	Collector assembly hardware kit, SB, SS
19	B06711	Shear bolts, package of 10 with locking hardware







30, 36, 45 SB Collector Assembly Diagram Key - Year Model 2019/01				
Item#	GXi Part	Description		
ILGIII #	Number	Description		
1	B00112	Snow tire and rim, SB, SS, includes shoulder bolt and locking nut		
2	B01110	Transmission belt, timing belt, SB, SS		
3	B01312	Belt guard, SB, SS, plastic, top retaining tab and with hardware		
4	B01910	Shift rod assembly, SB, SS, connects between shift handle and transmission linkage on chassis		
5	B02010	Auger/Impeller OR Transmission Engage cable, SB, SS, ONE cable per package, includes spring, adjustment tube, jam nut, and attachment rod		
6	B02212	Headlight assembly, SB, SS, includes bezel, light housing, bulb, and wires to first 2-pin connector		
7	B02510	Friction wheel assembly with bearings, SB, SS		
8	B02610	Chassis bottom cover, SB, SS, black with hardware		
9	B09012	Upper control handle assemlby, SB grey, includes left and right 30mm pistol grip handle, rubber handle grips, control panel, control panel cover, assembly hardware, controls label applied, and 30", 36", and 45" labels included - customer installs model label depending on their model		
10	B02812	Left snow blower control handle, SB grey, for 30mm handlebars, includes rubber grip, and hardware		
11	B02912	Right snow blower control handel, SB grey, for 30mm handlebars, includes rubber grip and hardware		
12	B03412	Handle grips, SB, 30mm pistol grip handlebars		
13	B03512	Chute direction control handle, SB, SS, includes crank handle, rubber knob, square cable receiver, bearings, and cable adapter		
14	B03811	Discharge chute angle lever, left, SB, SS, includes rubber grip, mounting hardware, and cable connection pivot		
15	B03911	Transmission speed shift lever, right, SB, SS, includes rubber grip, mounting hardware, and transmissioni shift rod connection pivot		
16	B04412	Control handle interlock assembly, SB, SS, includes rod, pivot tab, springs, end connections, and hardware		
17	B04511	Outter transmission shaft linkage, SB, SS, black, adapts transmission shift shaft on chassis to transmission control rod on control panel		
18	B04712	Lower handle bar frame, SB grey, 30mm lower handle bar with hardware to connect to chassis		
19	B04912	Transmission belt idle pulley assembly, SB, SS, includes idle pulley, radiused pivot arm, pivot bushing, tension spring and hardware		
20	B05011	Crankshaft pulley assemby, SB, SS, includes double-v impeller driving pulley, transmission timing belt driving pulley, retaining spacers, key, and hardware		
21	B05612	Transmission shift assembly, SB, SS, includes friction wheel shifting shaft, front shaft mount, outer transmission shift linkage, and hardware		

22	B09311	Friction wheel aluminum drive disc assemly, SB, SS, includes aluminum timing pulley / drive disc mounted to transmission pivot plate
23	B09412	Snow blower wheel retaining shoulder bolt, Set of 2, SB, SS
24	B09711	Intermediate transmission shaft, SB, SS, hex shaft / small driving gear with bearings, snap rings, and hardware
25	B02110	Discharge chute deflector cable, SB, SS, includes spring, spring guides and hardware
26	B01810	Chute direction control cable, SB, SS
27	B00412	Headlight switch and wiring harness, SB, SS, with two pin connectors, includes wire loom
28	B03012	One hole strap with rubber liner, SB, SS, retains chute rotation and deflector cables with mounting bolt
29	B10612	Auger/Impeller and transmission cable guide pulley kit, SB, SS, includes cable guide pulleys and mounting brackets
30	B08012	Chassis assembly hardware kit, SB, SS
31	B11112	Transmission pivot plate tab with hardware, SS, SB
32	B11212	Control panel cover, SB grey, with hardware
33	B11312	Wheel spacers, SB, SS, sets proper wheel clearance from chassis
34	B02513	Friction wheel assembly with bearing